



SELECTION GUIDELINE

	Wood	Metal Steel / Alloys	Concrete (All Types)	Masonry Brick / Stucco / Cinder Block	Plastic
	310	210	210	310	210
Alkyd (Lead Based)	210	210	210	210/310	210
Alkyd (Non-Lead Based)	310	210	210	310	210
ZINC BASED COATINGS:					
Inorganic Zinc**		210/ 510	210/ 510	210/ 510	
Organic Zinc		210/ 510	210	310	
POLYUREAS:					
		210/ 510	210	210	
EPOXIES:					
100% solids		210/510	210/510	210/510	210/510
Solvented / Water based		210/510	210/510	210/510	210/510
Water based		210/510	210/510	210/510	210/510
URETHANES					
Thin film	310	210	210	310	210
Rigid & Elastomeric	310	210	210	310	210
GRAFITTI					
Painted / non porous surface	unTagit 2020™		unTagit 2020™		unTagit 2020™
Un-painted / porous surface	310	210/510	310	310	unTagit 2020™
Penetrating Stains / sealers	310	210	310	310	

NOTES:

1. For Plexi-Glass, Lexan, glass: use unTAGit 2020 graffiti remover. Note: unTAGit 2020 will discolor auto glare reducing films.
2. Depending on formulation, some organic zincs may not be removed. Always try a test area for suitability.
3. Wherever there is a choice between 210 & 510 remember the following: If the coating has a "high build" or is reinforced with high percentage of solid content, then 510 will work faster than 210. However, 210 will lift more deeply, thoroughly and completely than 510. A second application may be needed with 510.
4. All Waverly strippers products NEED TIME to penetrate the coatings and lift them off. Most coatings lift off in 2 to 24 hours. If possible, spray the strippers on the coating in the afternoon and leave it overnight. By next morning the job is done. Allow extra time for cooler temperatures.
5. In many cases the coating type may be unknown. This chart is only a guideline. Always do a test patch to determine the product is best suited for the job and how much dwell time will be required to complete the job.